Preface

Usage

The manual contains information on installing, using, operation and maintenance of the Modular UPS. Please carefully read this manual prior to installation.

Users

Technical Support Engineer Maintenance Engineer

Note

Our company is providing a full range of technical support and services. Customer can contact our local office or customer service center for help.

The manual will update irregularly, due to the product upgrading or other reasons. Unless otherwise agreed, the manual is only used as guide for users and any statements or information contained in this manual make no warranty expressed or implied

Contents

Pre	face			I			
Cor	ntents			II			
1.	Safe	ety Prec	autions	IV			
2.	Ove	Overview					
	2.1.	Proc	duct Description	8			
	2.2.	Syst	tem conceptual diagram	8			
	2.3.	Pow	ver module conceptual diagram	8			
	2.4.	Wor	king Modes	9			
		2.4.1.	Normal mode	9			
		2.4.2.	Battery Mode	9			
		2.4.3.	Bypass Mode	10			
		2.4.4.	Maintenance Mode (Manual Bypass)	10			
		2.4.5.	ECO Mode	11			
		2.4.6.	Auto-restart Mode	12			
		2.4.7.	Frequency Converter Mode	12			
	2.5.	UPS	S Structure	12			
		2.5.1.	UPS Configure ration	12			
		2.5.2.	UPS Structure	13			
3.	Insta	allation		15			
	3.1.	Loca	ation	15			
		3.1.1.	Installation Environment				
		3.1.2.	Site Selection				
		3.1.3.	Weight and Dimensions	15			
	3.2.	Unlo	oading and Unpacking	17			
		3.2.1.					
	3.3.	18					
	3.4.		k mounting				
	3.5. Switch between single input and double input of cabinet						
	3.6.		ery				
	3.7.		le Entry				
	3.8.	Pow	ver Cables				
		3.8.1.	Specifications				
		3.8.2.	Specifications for Power Cables Terminal				
		3.8.3.	Circuit Breaker				
		3.8.4.	Connecting Power Cables				
	3.9.		trol and Communication Cables				
		3.9.1.	Dry Contact Interface				
		3.9.2.	Communication Interface.				
4.	-		ontrol and Display Panel				
	4.1.		S operator panel				
		4.1.1.	LED Indicator				
		4.1.2.	Control operation key				
		4.1.3.	LCD touch Screen	37			

	4.2 Main	Menu	38
	4.2.1	Cabinet	38
	4.2.2	Power module	40
	4.2.3	Setting.	42
	4.2.4	Log	44
	4.2.5	Operate	50
	4.2.6	Scope	52
5	Operation	IS	53
	5.1 U	PS Start-up	53
	5.1.1	Start in Normal Mode	53
	5.1.2	2. Start from Battery	54
	5.2. Pr	ocedure for Switching between Operation Modes	55
	5.2.1	. Switching the UPS into Battery Mode from Normal Mode	55
	5.2.2	2. Switching the UPS from Normal Mode into Bypass Mode	55
	5.2.3	Switching the UPS into Normal Mode from Bypass Mode	55
	5.2.4	Switching the UPS from Normal Mode into Maintenance BypassMode	55
	5.2.5	5. Switching the UPS into Normal Mode from Maintenance Bypass Mode	56
	5.3 Ba	attery Manual	56
	5.4 EI	20	57
	5.5 In	stallation of Parallel Operation System	58
6.	Maintena	nce	60
	6.1. Co	ontents of this chapter	60
	6.2. Sy	ystem maintenance instruction	60
	6.2.1	. Matters needing attention	60
	6.2.2	2. Instruction for Maintaining Power module	60
	6.2.3	Maintaining monitor unit and bypass unit for 6-slot cabinet	60
	6.2.4	Maintaining monitor unit and bypass unit for 8-slot cabinet	61
	6.2.5	Battery maintenance	61
	7.1. Co	ontents of this chapter	63
	7.2. A _l	pplicable Standards	63
	7.3. Er	nvironmental Characteristics	63
	7.4. M	echanical Characteristic	63
	7.5. El	ectrical Characteristics	64
	7.5.1	. Electrical Characteristics (Input Rectifier)	64
	7.5.2	2. Electrical Characteristics (Intermediate DC Link)	64
	7.5.3	Electrical Characteristics (Inverter Output)	65
	7.5.4	Electrical Characteristics (Bypass Mains Input)	65
	7.6. Ef	ficiency	66
	7.7. Di	isplay and Interface	66
Δn	nendiy I		67

1. Safety Precautions

This manual contains information concerning the installation and operation of Modular UPS. Please carefully read this manual prior to installation.

The Modular UPS cannot be put into operation until it is commissioned by engineers approved by the manufacturer (or its agent). Not doing so could result in personnel safety risk, equipment malfunction and invalidation of warranty.

Safety Message Definition

Danger: Serious human injury or even death may be caused, if this requirement is ignored.

Warning: Human injury or equipment damage may be caused, if this requirement is ignored.

Attention: Equipment damage, loss of data or poor performance may be caused, if this requirement is ignored.

Commissioning Engineer: The engineer who installs or operates the equipment should be well trained in electricity and safety and familiar with the operation, debug, and maintenance of the equipment.

Warning Label

The warning label indicates the possibility of human injury or equipment damage, and advises the proper step to avoid the danger. In this manual, there are three types of warning labels as below.

Labels	Description
Danger	Serious human injury or even death may be caused, if this requirement is ignored.
Warning	Human injury or equipment damage may be caused, if this requirement is ignored.
Attention	Equipment damage, loss of data or poor performance may be caused, if this requirement is ignored.

Safety Instruction

Danger	\$ \$	Performed only by commissioning engineers. This UPS is designed for commercial and industrial applications only, and
		is not intended for any use in life-support devices or system.
Warning	*	Read all the warning labels carefully before operation, and follow the instructions.
		When the system is running, do not touch the surface with this label, to avoid any hurt of scald.
		ESD sensitive components inside the UPS, anti-ESD measure should be taken before handling.

Move & Install

Danger	 ♦ Keep the equipment away from heat source or air outlets. ♦ In case of fire, use dry powder extinguisher only, any liquid extinguisher can result in electric shock. 	
Warning	Do not start the system if any damage or abnormal parts founded. Contacting the UPS with wet material or hands may be subject to electric shock.	
Attention	 ♦ Use proper facilities to handle and install the UPS. Shielding shoes, protective clothes and other protective facilities are necessary to avoid injury. ♦ During positioning, keep the UPS way from shock or vibration. ♦ Install the UPS in proper environment, more detail in section 3.3. 	

Debug & Operate

	\$	Make sure the grounding cable is well connected before connecting the
		power cables, the grounding cable and neutral cable must be in accordance
		with the local and national codes practice.
	\$	Before moving or re-connecting the cables, make sure to cut off all the
1		input power sources, and wait for at least 10 minutes for internal discharge.
Danger		Use a multi-meter to measure the voltage on terminals and ensure the
		voltage is lower than 36V before operation.
		Risk of Voltage Back feed. Before working on the circuits, isolate the
		Uninterruptible Power Supply (UPS), and then check for Hazardous
		Voltage between all terminals including the protective earth.
Δ.		The earth leakage current of load will be carried by RCCB or RCD.
Attention	\$	Initial check and inspection should be performed after long time storing of
		UPS.

Maintenance & Replacement



- All the equipment maintenance and servicing procedures involving internal access need special tools and should be carried out only by trained personnel. The components that can only be accessed by opening the protective cover with tools cannot be maintained by user.
- ♦ This UPS full complies with "IEC62040-1-1-General and safety requirements for use in operator access area UPS". Dangerous voltages are present within the battery box. However, the risk of contact with these high voltages is minimized for non-service personnel. Since the component with dangerous voltage can only be touched by opening the protective cover with a tool, the possibility of touching high voltage component is minimized. No risk exists to any personnel when operating the equipment in the normal manner, following the recommended operating procedures in this manual.
- ♦ Risk of Fire. TO REDUCE THE RISK OF RIFE, REPLACE FUSES WITH THE SAME TYPE AND RATINGS. DISCONNECT OUTPUT AND ALL INPUT SOURCES OF POWER FROM THIS EQUIPMENT BEFORE SERVICING.

Battery Safety

- All the battery maintenance and servicing procedures involving internal access need special tools or keys and should be carried out only by trained personnel.
- WHEN CONNECTED TOGETHER, THE BATTERY TERMINAL VOLTAGE WILL EXCEED 400Vdc AND IS POTENTIALLY LEATHAL.
- Battery manufacturers supply details of the necessary precautions to be observed when working on, or in the vicinity of, a large bank of battery cells. These precautions should be followed implicitly at all times. Particular attention should be paid to the recommendations concerning local environmental conditions and the provision of protective clothing, first aid and fire-Figure ting facilities.



- Ambient temperature is a major factor in determining the battery capacity and life. The nominal operating temperature of battery is 20°C. Operating above this temperature will reduce the battery life. Periodically change the battery according to the battery user manuals to ensure the back-up time of LIDS.
- ♦ Replace the batteries only with the same type and the same number, or it may cause explosion or poor performance.
- ♦ When connecting the battery, follow the precautions for high-voltage operation before accepting and using the battery, check the appearance the battery. If the package is damaged, or the battery terminal is dirty, corroded or rusted or the shell is broken, deformed or has leakage, replace it with new product. Otherwise, battery capacity reduction, electric leakage or fire may be caused
 - Before operating the battery, remove the finger ring, watch, necklace, bracelet and any other metal jewelry
 - Wear rubber gloves.
 - Eye protection should be worn to prevent injury from accidental

electrical arcs.

- Only use tools (e.g. wrench) with insulated handles.
- The batteries are very heavy. Please handle and lift the battery with proper method to prevent any human injury or damage to the battery terminal.
- Do not decompose, modify or damage the battery. Otherwise, battery short circuit, leakage or even human injury may be caused.
- The battery contains sulfuric acid. In normal operation, all the sulfuric acid is attached to the separation board and plate in the battery. However, when the battery case is broken, the acid will leak from the battery. Therefore, be sure to wear a pair of protective glasses, rubber gloves and skirt when operating the battery. Otherwise, you may become blind if acid enters your eyes and your skin may be damaged by the acid.
- At the end of battery life, the battery may have internal short circuit, drain of electrolytic and erosion of positive/negative plates. If this condition continues, the battery may have temperature out of control, swell or leak. Be sure to replace the battery before these phenomena happen.
- If a battery leaks electrolyte, or is otherwise physically damaged, it
 must be replaced, stored in a container resistant to sulfuric acid and
 disposed of in accordance with local regulations.
- If electrolyte comes into contact with the skin, the affected area should be washed immediately with water.

Disposal



Dispose of used battery according to the local instructions

2. Overview

2.1. Product Description

The RM series Modular UPS is an online double-conversion UPS that uses digital signal processing (DSP) technology. Provide a stable and uninterrupted power supply for the important load.

2.2. System conceptual diagram

The Modular UPS is configured by the following part: Power modules, Bypass & Monitoring unit, and cabinet with manual Bypass switch. One or several battery strings should be installed to provide backup energy once the utility fails. The UPS structure is shown in Figure 2-1:




Figure 2-1 UPS Conceptual Diagram

2.3. Power module conceptual diagram

The power module conceptual diagram is shown as Figure 2-2. The Power module contains a rectifier, an inverter, and a DC/DC converter for charge and discharge of the external batteries.




Figure 2-2 Power module conceptual diagram

2.4. Working Modes

The Modular UPS is an on-line, double-conversion UPS that permits operation in the following modes:

- Normal mode
- Battery mode
- Bypass mode
- Maintenance mode (manual bypass)
- ECO mode
- Auto-restart mode
- Frequency Converter mode

2.4.1. Normal mode

The inverter of power modules continuously supply the critical AC load. The rectifier/charger derives power from the AC mains input source and supplies DC power to the inverter while simultaneously FLOAT or BOOST charging its associated backup battery. As Figure 2-3 shows




Figure 2-3 UPS conceptual diagram in normal mode



Indicates the energy flow direction.

2.4.2. Battery Mode

Upon failure of the AC mains input power, the inverter of power module, which obtains power from the battery, supply the critical AC load. There is no interruption in power to the critical load upon failure. After restoration of the AC mains input power, the "Normal mode" operation will continue automatically without the necessity of user intervention. As Figure 2-4 shows.




Figure 2-5 UPS conceptual diagram in Battery mode



With the function of Battery cold start, the UPS may start without utility.

2.4.3. Bypass Mode

If the inverter overload capacity is exceeded under Normal mode, or if the inverter becomes unavailable for any reason, the static transfer switch will perform a transfer of the load from the inverter to the bypass source, with no interruption in power to the critical AC load. Should the inverter be asynchronous with the bypass, the static switch will perform a transfer of the load from the inverter to the bypass with power interruption to the load. This is to avoid large cross currents due to the paralleling of unsynchronized AC sources. This interruption is programmable but typically set to be less than 3/4 of an electrical cycle, e.g., less than 15ms (50Hz) or less than 12.5ms (60Hz). The action of transfer/re-transfer can also be done by the command through monitor. As Figure 2-6 shows.




Figure 2-6 UPS conceptual diagram in Bypass Mode

2.4.4. Maintenance Mode (Manual Bypass)

A manual bypass switch is available to ensure continuity of supply to the critical load when the UPS becomes unavailable e.g. during a maintenance procedure. As Figure 2-7 shows.




Figure 2-7 UPS conceptual diagram in Maintenance Mode



Danger

- During Maintenance mode, dangerous voltages are present on the terminal of input, output and neutral, even with all the modules and the LCD turned off.
- The UPS which without External maintenance switch in Maintenance Mode, dangerous voltages are present on terminal and internal Copper bar.

2.4.5. ECO Mode

The economy control operation (ECO) mode is an energy-saving mode, In ECO mode, when the bypass input voltage is within the ECO voltage range, the static bypass turns on, and the bypass supplies power, and inverter is standby. When the bypass input voltage is beyond the ECO voltage range, the UPS transfers from bypass mode to normal mode. As Figure 2-8 shows.




Figure 2-8 UPS conceptual diagram in ECO Mode

2.4.6. Auto-restart Mode

The battery may become exhausted following an extended AC mains failure. The inverter shuts down when the battery reaches the End of Discharge Voltage (EOD). The UPS may be programmed to "System Auto-Start Mode after EOD". The system starts after a delay time when the AC main recovers. The mode and the delay time are programmed by the commissioning engineer.

2.4.7. Frequency Converter Mode

By setting the UPS to Frequency Converter mode, the UPS could present a stable output of fixed frequency (50 or 60Hz), and the bypass static switch is not available.

2.5. UPS Structure

2.5.1. UPS Configure ration


The UPS configure ration is provided in Table 2-1.

Table 2-1 UPS ConFigureuration

Item	Components	Quantity/ pcs	Remark
6-slot Cabinet	Bypass & Monitoring unit	1	factory installed
0 alot Cobinot	Manual Bypass Breaker	1	factory installed
8-slot Cabinet	Bypass & Monitoring unit	1	factory installed
25kVA Power module	Bypass unit	1~8	/

2.5.2. UPS Structure

The UPS structure is shown in Figure 2-9.



(a) 6-slot UPS Cabinet structure






Figure 2-9 UPS Cabinet structure (front view)

Back view as Figure 2-10 shows.



(a) 6 slot UPS Cabinet structure (back view)



(b) 8 slot UPS Cabinet structure (back view)

Figure 2-10 UPS Cabinet structure (back view)

3. Installation

3.1. Location

As each site has its requirements, the installation instructions in this section are to act as a guide for the general procedures and practices that should be observed by the installing engineer

3.1.1. Installation Environment

- The UPS is intended for indoor installation and uses forced convection cooling by internal fans. Please make sure there is enough space for the UPS ventilation and cooling.
- Keep the UPS far away from water, heat and inflammable and explosive, corrosive material. Avoid installing
 the UPS in the environment with direct sunlight, dust, volatile gases, corrosive material and high salinity.
- Avoid installing the UPS in the environment with conductive dirt.
- The operating environment temperature for battery is 20°C-25°C. Operating above 25°C will reduce the battery life, and operation below 20°C will reduce the battery capacity.
- The battery will generate a little amount of hydrogen and oxygen at the end of charging; ensure the fresh air volume of the battery installation environment must meet EN50272-2001 requirements.
- If external batteries are to be used, the battery circuit breakers (or fuses) must be mounted as close as possible to the batteries, and the connecting cables should be as short as possible.

3.1.2. Site Selection

Ensure the ground or installation platform can bear the weight of the UPS cabinet, batteries and battery rack.



The UPS cabinet, battery can battery racks are suitable for mounting on concrete or other non-combustible surface

No vibration and less than 5 degree inclination horizontally.

The equipment should be stored in a room so as to protect it against excessive humidity and heat sources.


The battery needs to be stored in dry and cool place with good ventilation. The most suitable storage temperature is 20 °C to 25°C.

3.1.3. Weight and Dimensions



Attention

Ensure there is at least 0.8m before the front of the cabinet so as to easily maintain the power module with the front door fully open and at least 0.5m behind for ventilation and cooling.



(b) Dimensions of 8-slot Cabinet (unit: mm) Figure 3-1 Dimensions of Cabinet (unit: mm)

Ensure that the floor or installation support can bear the weight of the UPS, batteries, and battery racks. The weight of batteries and battery racks depends on the site requirements. The weight for the UPS cabinet is shown in Table 3-1.

Table 3-1 Weight for the UPS

Capacity	Weight
PM25C	18Kg
6-slot Cabinet	116Kg
8-slot Cabinet	200Kg

3.2. Unloading and Unpacking

3.2.1. Moving and Unpacking of the Cabinet

The steps to move and unpack the cabinet are as follows:

- Check if any damages to the packing. (If any, contact to the carrier) Transport the equipment to the designated site by forklift, as shown in Figure 3-2; 2)




Figure 3-2 Transport to the designated site

3) Open the top plate of the steel-edged wooden case with slotted awl and pier, followed by sideboards (see Figure 3-3;



Figure 3-3 Remove the protective foam

- 4) Remove the protective foam around the cabinet.
- 5) Check the UPS.

Visually examine if there are any damages to UPS during transportation. If any, contact to the carrier.;

Check the UPS with the list of the goods. If any items are not included in the list, contact to our company or the local office

- 6) Dismantle the bolt that connects the cabinet and wooden pallet after disassembly.
- 7) Move the cabinet to the installation position.



Be careful while removing to avoid scratching the equipment.




Attention


The waste materials of unpacking should be disposed to meet the demand for environmental protection.

3.3. Positioning

The 8-slot cabinet has two way of supporting itself: One is to support itself temporarily by the four wheels at the bottom, making it convenient to adjust the position of the cabinet; the other is by anchor bolts to support the cabinet permanently after adjusting the position of the cabinet. The 6-slot cabinet has stationary barrier, it does not have wheels. The supporting structure is shown in Figure 3-4.



(a) Supporting structure of 6-slot Cabinet (Bottom view, unit: mm)



(b) Supporting structure of 8-slot Cabinet (Bottom view, unit: mm)

Figure 3-4 Supporting structure (Bottom view)

When installing the 6-slot UPS, use the fork lift truck to transport the cabinet directly to the installation position.

The steps to position the 8-slot cabinet are as follows:

- 1) Ensure the supporting structure is in good condition and the mounting floor is smooth and strong.
- 2) Retract the anchor bolts by turning them counter clock wise using wrench. The cabinet is then supported by the four wheels
- 3) Adjust the cabinet to the right position by the supporting wheels.
- 4) Put down the anchor bolts by turning them clock wise using wrench, the cabinet is then supported by the four anchor bolts.
- 5) Ensure the four anchor bolts are in the same height and the cabinet is fixed and immovable.
- 6) Positioning done.



Attention

- Auxiliary equipment is needed when the mounting floor is not solid enough to support the cabinet, which
 helps distribute the weight over a larger area. For instance, cover the floor with iron plate or increase the
 supporting area of the anchor bolts.
- Reserve at least 0.8 meters in front of the cabinet to replace the power module and bypass module. The
 cabinet should be reserved for at least 0.5 meters space in back for air flow and heat dissipation, As
 Figure 3-5 shows.




Figure 3-5 Cabinet space reservation schematic (unit: mm)

3.4. Rack mounting

The UPS system supports rack mounting to meet the application requirements of the micro modular machine room. The specific procedures for installing the UPS rack are as follows:

1. Remove cabinet trim strip, as Figure 3-6 shows;




Figure 3-6 Remove cabinet trim strip

2. Remove the side door of the cabinet, as Figure 3-7 shows;




Figure 3-7 Remove the side door of the cabinet

3. Remove bracket for cabinet side door, as Figure 3-8 shows;




Figure 3-8 Remove bracket for cabinet side door

4. Install rack tray on the server cabinet, as Figure 3-9 shows;




Figure 3-9 Install rack tray

5. Load the UPS into the server cabinet, place on rack tray, and lock the bypass module and the manual bypass switch panel screws(6-slot cabinet needs to remove stationary barrier first), as Figure 3-10 shows;




Figure 3-10 Load the UPS into the server cabinet

6. Insert module to cabinet, and lock the module panel screws, as Figure 3-11 shows;




Figure 3-11 Insert module to cabinet

7. Complete installation

3.5. Switch between single input and double input of cabinet

When the UPS cabinet leaves the factory, it defaults to a single input configuration.

The 6-slot cabinet needs to be matched with PDU to have dual input function and can only be configured by the manufacturer.

8 Change single input to dual input , $\,$ just need to remove the main input and the bypass input short connecting copper bar. As Figure 3-12 shows $_{\circ}$




Figure 3-12 Remove the main input and the bypass input short connecting copper bar

3.6. Battery

Three terminals (positive, neutral, negative) are drawn from the battery unit and connected to UPS system. The neutral line is drawn from the middle of the batteries in series. See Figure 3-13




Figure 3-13 Battery string wiring diagram




Danger

The battery terminal voltage is of more than 200Vdc, please follow the safety instructions to avoid electric shock hazard.


Ensure the positive, negative, neutral electrode is correctly connected from the battery unit terminals to the breaker and from the breaker to the UPS system.

3.7. Cable Entry

Cables can enter the 6-slot cabinet from the top. The cable entry is shown in Figure 3-14



(a) Cable Entry of 6-slot Cabinet



(b) Cable Entry of 8-slot Cabinet

Figure 3-14 Cable Entry

3.8. Power Cables

3.8.1. Specifications

The selection of power cable in UPS system should meet the requirements of Table 3B in IEC60950-1, and select suitable cable in combination with practical engineering applications, UPS working current shows in Table 3-2.

Table 3-2 UPS working current

	Contents	6-solt cabinet	8-solt cabinet
Main Input	Main Input Current(A)	293	391
Main Input	Main output Current(A)	227	303
Bypass Input	Bypass Input Current(A)	227	303
Battery input	Battery Input Current(A)	340	453



The recommended cable section for power cables are only for situations described below:

- Ambient temperature: 30°C.
- AC loss less than 3%, DC loss less than 1%, The length of the AC power cables are no longer than 50 m and the length of the DC power cables are no longer than 30 m.
- Currents listed in the table are based on the 380V system (Line-to-line voltage).
- The size of neutral lines should be 1.5~1.7 times the value listed above when the predominant load is non-linear.

3.8.2. Specifications for Power Cables Terminal

Specifications for power cables connector are listed as Table 3-3.

Table 3-3 Requirements for power module terminal

Cabinet	Port	Connection	Туре	Bolt	Torque Moment
	Mains input	Cables crimped OT terminal	150-10	M10	15Nm
	Bypass Input	Cables crimped OT terminal	150-10	M10	15Nm
6-slot	Battery Input	Cables crimped OT terminal	150-10	M10	15Nm
	Output	Cables crimped OT terminal	150-10	M10	15Nm
	PE	Cables crimped OT terminal	150-10	M10	15Nm
	Mains input	Cables crimped OT terminal	240-10	M10	15Nm
	Bypass Input	Cables crimped OT terminal	240-10	M10	15Nm
8-slot	Battery Input	Cables crimped OT terminal	240-10	M10	15Nm
	Output	Cables crimped OT terminal	240-10	M10	15Nm
	PE	Cables crimped OT terminal	240-10	M10	15Nm

3.8.3. Circuit Breaker

The circuit breakers (CB) for the system are recommended in Table 3-4.

Table 3-4 Recommended CB

Installed position	6-slot cabinet	8-slot cabinet
Main input CB	250A /3P	400A/3P
Bypass input CB	250A/3P	400A/3P
Output CB	250A /3P	400A/3P
Manual	250A/3P	400A/3P
Bypass CB	20011/21	1001231
Battery CB	400A DC	630A DC




Attention

The CB with RCD (Residual Current Device) is not suggested for the system

3.8.4. Connecting Power Cables


The steps of connecting power cables are as follows:

- 1) Verify that all the switches of the UPS are completely open and the UPS internal maintenance bypass switch is opened. Attach necessary warning signs to these switches to prevent unauthorized operation.
- 2) Open the front door of the cabinet (10-slot Cabinet open the back door), remove the plastic cover. The input and output terminal, battery terminal and protective earth terminal are shown in Figure 3-15:




(a) Connections terminals of 6-slot cabinet

single AC input connection



(b) Connections terminals of 8-slot cabinet

split AC input connection



(c) Connections terminals of 8-slot cabinet (dual input)

Figure 3-15 Connections terminals

- 3) Connect the protective earth wire to protective earth terminal (PE).
- 4) Connect the AC input supply cables to the Input terminal and AC output supply cables to the Output terminal. See Figure 3-15
- 5) Connect the Battery cables to the Battery terminal.
- 6) Check to make sure there is no mistake and re-install all the protective covers.




Warning

 Tighten the connections terminals to enough torque moment, refer to 3-3, and please ensure correct phase rotation.


- The grounding cable and neutral cable must be connected in accordance with local and national codes.
- Load must be connected to the same ground as that of UPS system

3.9. Control and Communication Cables

The back panel of the bypass module provides dry contact interface (J2-J11) and communication interface (RS232, RS485, SNMP, SNMP card interface and Parallel interface), as it is shown in Figure 3-16.



(a) Communication interface of 6-slot cabinet



(b) Communication interface of 8-slot cabinet

Figure 3-16 Communication interface

3.9.1. Dry Contact Interface

Dry contact interface includes port J2-J11 and the functions of the dry contact are shown in Table 3-5

Table 3-5 Functions of the port

Port	Name	Function
J2-1	TEMP_BAT	Detection of battery temperature
J2-2	TEMP_COM	Common terminal for temperature detection
J3-1	ENV_TEMP	Detection of environmental temperature
J3-2	TEMP_COM	Common terminal for temperature detection
J4-1	REMOTE_EPO_NC	Trigger EPO when disconnect with J4-2
J4-2	+24V_DRY	+24V
J4-3	+24V_DRY	+24V
J4-4	REMOTE_EPO_NO	Trigger EPO when shorted with J4-3
J5-1	+24V_DRY +24V	
J5-2	GEN_CONNECTED	Input dry contact, function is settable,

		Default: interface for generator
J5-3	GND_DRY	Ground for +24V
J6-1	BCB Drive	Output dry contact, function is settable.
		Default: Battery trip signal
16.2	DCD CL	Input dry contact, function is settable.
J6-2	BCB_Status	Default: BCB Status and BCB Online, (Alert no battery when
J7-1	CND DBV	BCB Status is invalid).
J / - 1	GND_DRY	Ground for +24V
17.2	DCD Online	Input dry contact, function is settable.
J7-2	BCB_Online	Default: BCB Status and BCB Online (Alert no battery when BCB Status is invalid).
		Output dry contact (Normally closed), function is settable.
J8-1	BAT_LOW_ALARM_NC	Default: Low battery alarming
		, c
J8-2	BAT_LOW_ALARM_NO	Output dry contact (Normally open), function is settable.
J8-3	BAT LOW ALARM GND	Default: Low battery alarming
J8-3	BAI_LOW_ALARWI_GND	Common terminal for J8-1 and J8-2
J9-1	GENERAL_ALARM_NC	Output dry contact, (Normally closed) function is settable.
		Default: Fault alarming
J9-2	GENERAL ALARM NO	Output dry contact, (Normally open) function is settable.
		Default: Fault alarming
J9-3	GENERAL_ALARM_GND	Common terminal for J9-1 and J9-2
J10-1	LITH ITV FAIL NO	Output dry contact, (Normally closed) function is settable.
310-1	UTILITY_FAIL_NC	Default: Utility abnormal alarming
J10-2	UTILITY_FAIL_NO	Output dry contact, (Normally open) function is settable.
J10-2	OTILITI_FAIL_NO	Default: Utility abnormal alarming
J10-3	UTILITY_FAIL_GND	Common terminal for J10-1 and J10-2



The settable functions for each port can be set by the monitor software.

The default functions of each port are described as follows.

Battery Warning Output Dry Contact Interface

The input dry contact J2 and J3 can detect the temperature of batteries and environment respectively, which can be used in environment monitoring and battery temperature compensation.

Interfaces diagram for J2 and J3 are shown in Figure 3-17, the description of interface is in Table 3-6 $^{\circ}$




Figure 3-17 J2 and J3 for temperature detecting

Table 3-6 Description of J2 and J3

Port	Name	Function
J2-1	TEMP_BAT	Detection of battery temperature
J2-2	TEMP_COM	common terminal
J3-1	ENV_TEMP	Detection of environmental temperature
J3-2	TEMP_COM	common terminal



Specified temperature sensor is required for temperature detection (R25=5Kohm, B25/50=3275), please confirm with the manufacturer, or contact the local maintenance engineers when placing an order.

Remote EPO Input Port

J4 is the input port for remote EPO. It requires shorting NC and \pm 24V and disconnecting NO and \pm 24V during normal operation, and the EPO is triggered when opening NC and \pm 24V or shorting the NO and \pm 24V. The port diagram is shown in Figure 3-18 and port description is shown in Table 3-7.




Figure 3-18 Diagram of input port for remote EPO

Table 3-7 Description of input port for remote EPO

Port	Name	Function
J4-1	REMOTE_EPO_NC	Trigger EPO when disconnect with J4-2
J4-2	+24V_DRY	+24V

J4-3	+24V_DRY	+24V
J4-4	REMOTE_EPO_NO	Trigger EPO when connect with J4-3

UPS system in normal operation, port J4-2 to J4-1 should short circuit, and J4-3 to J4-4 should be open.

Generator Input Dry Contact

The default function of J5 is the interface for generator J5 Connect pin 2 of J5 with \pm 24V power supply; it indicates that the generator has been connected with the system. The interface diagram is shown in Figure 2-19, and interface description is shown in Table 3-8.




Figure 3-19 Diagram of status interface and connection of generator

Table 3-8 Description of status interface and connection of generator

Port	Name	Function
J5-1	+24V_DRY	+24V
J5-2	GEN_CONNECTED	Connection status of generator
J5-3	GND_DRY	Power ground for +24V

BCB Input Port

The default function of J6 and J7 are the ports of BCB. The port diagram is shown in Figure 3-20, and description is shown in Table 3-9.




Figure 3-20 BCB Port

Table 3-9 Description of BCB port

Port	Name	Function
J6-1	BCB DRIV	BCB contact drive, provides +24V voltage, 20mA
J0-1	DCD_DKIV	drive signal
J6-2	BCB_Status	BCB contact status, connect with the normally
J0-2		open signal of BCB
J7-1	GND_DRY	Power ground for +24V
J7-2	BCB_Online	BCB on-line input (normally open), BCB is
		on-line when the signal is connecting with J7-1

Battery Warning Output Dry Contact Interface

The default function of J8 is the output dry contact interface, which presents the battery warnings of low or excessive voltage, when the battery voltage is lower than set value, an auxiliary dry contact signal will be activated via the isolation of a relay. The interface diagram is shown in Figure 3-21, and description is shown in Table 3-10.




Figure 3-21 Battery warning dry contact interface diagram

Table 3-10 Battery warning dry contact interface description

Port	Name	Function
J8-1	BAT LOW ALARM NC	Battery warning relay (normally closed) will be
30-1	BAI_LOW_ALARMI_NC	open during warning
J8-2	BAT LOW ALARM NO	Battery warning relay (normally open) will be
		closed during warning
J8-3	BAT_LOW_ALARM_GND	Common terminal

General Alarm Output Dry Contact Interface

The default function of J9 is the general alarm output dry contact interface. When one or more warnings are triggered, an auxiliary dry contact signal will be active via the isolation of a relay. The interface diagram is shown in Figure 3-22, and description is shown in Table 3-11.




Figure 3-22 Integrated warning dry contact interface diagram

Table 3-11 General alarm dry contact interface description

Port	Name	Function
J9-1	GENERAL ALARM NC	Integrated warning relay (normally closed) will be
37 1	GENERAL_NEARINITY	open during warning
J9-2	GENERAL ALARM NO	Integrated warning relay (normally open) will be
39-2	GENERAL_ALARM_NO	closed during warning
J9-3	GENERAL_ALARM_GND	Common terminal

Utility Fail Warning Output Dry Contact Interface

The default function of J10 is the output dry contact interface for utility failure warning, when the utility fails, the system will send a utility failure warning information, and provide an auxiliary dry contact signal via the isolation of a relay. The interface diagram is shown in Figure 3-23, and description is shown in Table $3-12^{\circ}$




Figure 3-23 Utility failure warning dry contact interface diagram

Table 3-12 Utility failure warning dry contact interface description

Port Name Function

Port	Name	Function
J10-1	UTILITY FAIL NC	Mains failure warning relay(normally closed) will
310 1	OTILITI_TAIL_IVE	be open during warning
J10-2	UTILITY FAIL NO	Mains failure warning relay (normally open) will
310-2	OTETT_TAIL_NO	be closed during warning
J10-3	UTILITY_FAIL_GND	Common terminal

3.9.2. Communication Interface


RS232, RS485 and USB port: Provide serial data which can be used for commissioning and maintenance by authorized engineers or can be used for networking or integrated monitoring system in the service room.

SNMP: Used on site installation for communication (Optional).

4. Operator Control and Display Panel

4.1. UPS operator panel

The structure of operator control and display panel for cabinet is shown in Figure 4-1



1: LCD touch screen
 2: EPO switch
 3: Audible Alarm (Buzzer)
 4: Status indicator
 5: Bypass indicator
 6: Rectifier indicator
 7: Inverter indicator
 8: Load indicator
 9: Battery indicator
 10: Bypass transfer
 11: Inverter transfer
 12: Mute

Figure 4-1 Control and display panel

4.1.1. LED Indicator

There are 6 LEDs on the panel to indicate the operating status and fault. The description of indicators is shown in 4-1.

4-1 Status description of indicator

Indicator	State	Description	
	Steady	Rectifier normal for all modules	
	green	Received normal for an modules	
	Flashing	Rectifier normal for at least one module, mains normal	
Rectifier	green	Receited normal for at least one module, mains normal	
indicator	Steady red	Rectifier fault	
	Flashing	Mains abnormal for at least one module	
	red	iviants abhormat for at least one module	
	Off	Rectifier not operating	
Battery	Steady	Battery charging	
indicator	green		

Indicator	State	Description
	Flashing green	Battery discharging
	Steady red	Battery abnormal (battery failure, no battery or battery reversed) or battery converter abnormal (failure, over current or over temperature), EOD
	Flashing red	Battery low voltage
	Off	Battery and battery converter normal, battery not charging
	Steady green	Load supplied by bypass
Bypass indicator	Steady red	Bypass abnormal or out of normal range, or static bypass switch fault
mulcator	Flashing red	Bypass voltage abnormal
	Off	Bypass normal
	Steady green	Load supplied by inverter
	Flashing	Inverter on, start, synchronization or standby (ECO mode) for at
Inverter indicator	green	least one module
	Steady red	System output not supplied by inverter, inverter fault for at least one module.
	Flashing	System output supplied by inverter, inverter fault for at least one
	red	module.
	Off	Inverter not operating for all modules
Load indicator	Steady	UPS output ON and normal
	green	of 5 output of valid normal
	Steady red	UPS overload time is out, or output short, or output no power supply
	Flashing red	Overload output of UPS
	Off	No output of UPS
Status indicator	Steady green	Normal operation
1114104101	Steady red	Failure

There are two different types of audible alarm during UPS operation, as shown in Table $4-2\,$ \circ

Table 4-2 Description of audible alarm

Alarm	Description
Two short alarm with a	when system has general alarm (for example: AC fault),
long one	when system has general alarm (for example. AC fault),
Continuous alarm	When system has serious faults (for example: fuse blown or hardware
	failure)

4.1.2. Control operation key

Control and operation keys include four keys of 2, 10, 11 and 12, which are used together with LCD touch screen. The functions description is shown in Table 4-3

Table 4-3 Functions of Control and operation keys

Function Key	Description
EDO	Long press, cut off the load power (shut down the rectifier, inverter,
EPO	static bypass and battery)
BYP	Long press, transfer to the bypass
INV	Long press, transfer to the inverter
MUTE	Long press to switch between turning off and on the buzzing

4.1.3. LCD touch Screen

After the monitoring system starts self-test, the system enters the home page, following the welcome window. The home page is shown in Figure 4-2




Figure 4-2 Home page

Home page consists of Status bar, Information display, warning information and main menu.

Status bar

The Status bar contains the model of the product, capacity, operational mode, and the number of the power module and the time of the system.

• Warning Information

Display the warning information of the cabinet.

• Information Display

Users can check the information of the cabinet in this area.

The bypass voltage, main input voltage, battery voltage, and output voltages are presented in the form of gauge.

The loads are displayed in the form of bar chart in percentage. The green area stands for a load of less than 60%, yellow area for a load of 60%-100% and red area for a load of more than 100%.

The energy flow mimics the flow of the power.

• Main Menu

The main menu includes Cabinet, Power m, setting, log, Operate and Scope. Users can operate and control the UPS,

and browse all measured parameters through main menu.

The structure of the main menu tree is shown in Figure 4-3




Figure 4-3 Structure of menu tree

4.2 Main Menu

The main menu includes Cabinet, Power module, Setting, Log, Operate and Scope and it is described in details below.

4.2.1 Cabinet

Touch the icon Cabinet, (At the bottom left of the screen), and the system enters the page of the Cabinet, as it is shown in Figure 4-4




Figure 4-4 Cabinet

The Cabinet comprises sectors of title, information display, version running status, information display and submenu. The sectors are described as follows.

Title

Display the information of the selected submenu.

• Running status

The squares shown on the mini current path represent the various UPS power paths and show the current UPS operating status. (The green square indicating the block working normally, the white indicating the absent of the block and red indicating the absence of the block or in fault).

• Version Information

The version information for LCD of the cabinet and monitor.

Submenu

It includes the submenu of Bypass, Main, Output, load and battery.

• Information display


Display information of each submenu.

The interface of each submenu is shown in Figure.



(a) Interface of Main

(b) Interface of Output



(d) Interface of Load

(d) Interface of Battery

Figure 4-5 Submenu interface of Cabinet

The submenu of Cabinet is described in details below in Table 4-4

Table 4-4 Description of each submenu of Cabinet

Submenu Name	Contents	Meaning
Main	V	Phase voltage
Main	A	Phase current

Submenu Name	Contents	Meaning
	Hz	Input frequency
	PF	Power factor
	V	Phase voltage
D	A	Phase current
Bypass	Hz	Bypass frequency
	PF	Power factor
	V	Phase voltage
	A	Phase current
Output	Hz	Output frequency
	PF	Power factor
	kVA	Sout: Apparent Power
T 1	kW	Pout: Active Power
Load	kVar	Qout: Reactive power
	%	Load (The percentage of the UPS load)
	V	Battery positive/negative Voltage
	A	Battery positive/negative Current
	Capacity (%)	The percentage compared with new battery
	Capacity (70)	capacity
Dattory	Remain T (Min)	Remaining battery backup time
Battery	Battery(°C)	Battery Temp
	Ambient(°C)	Environmental Temp
	Total Work T	Total work time
	Total Discharge T	Total discharging time

4.2.2 Power module

Touch the icon dodule, (At the bottom left of the screen), and the system enters the page of the Power unit, as is shown in Figure.




Figure 4-6 Power module

The module comprises sectors of title, information display, power module information, version information and submenu. The sectors are described as follows.

• Title

Present the title of submenu of the selected power module.

• Information display

Display information of each submenu.

Power module information

The users can choose the power module to browse the information in the "Information display" sector.

Colors of the square on the mimic current path represent the various power module paths and show the current operating status.

- (a) The green square indicating the power module working normally,
- (b) The black indicating power module in invalid
- (c) The red indicating the absence of the power module or in fault

Take the 5#power module for example. It indicates that UPS is in Normal mode and the rectifier and inverter are working normally .The battery is not connected.

Version Information

The version information for rectifier and inverter of the selected power module.

Submenu

The submenu includes Input, Output, Load, INFO and S-CODE.

Users can enter the interface of each submenu by directly touching the icon .Each interface of the submenu is shown in Figure.



(c) Interface of Information

(d) Interface of S-Code

Figure 4-7 Module menu

The submenus of Power module are described below in details in Table .

Table 4-5 Description of each submenu of Power module

Submenu Name	Contents	Meaning
	V	Input phase voltage of selected module
T .	A	Input phase current of selected module
Input	Hz	Input frequency of selected module
	PF	Input power factor of selected module
	V	Output phase voltage of selected module
	A	Output phase current of selected module
Output	Hz	Output frequency of selected module
	PF	Output power factor of selected module
	V	Load voltage of selected module
Load	%	Load (The percentage of the power module selected)
Load	KW	Pout: Active Power
	KVA	Sout: Apparent Power
	BATT+(V)	Battery Voltage (positive)
	BATT-(V)	Battery Voltage (negative)
	BUS(V)	Bus Voltage(Positive &Negative)
	Charger(V)	Charger Voltage(Positive &Negative)
Information	Fan Time	Total Fan's Running time of the selected power module
	Inlet Temperature(°C)	Inlet Temperature of the selected power module
	Outlet	Outlet Temperature of the selected power module
	Temperature(°C)	Outlet Temperature of the selected power module
S-code	Fault Code	For the maintenance personnel

4.2.3 Setting

Touch the icon (At the bottom of the screen), and the system enters the page of the Setting, as it is shown in Figure.




Figure 4-8 Setting menu

The submenus are listed on the right side of the Setting page. Users can enter each of the setting interfaces by touching the relevant icon. The submenus are described in details below in Table .

Table 4-6 Description of each submenu of Setting

Submenu Name	Contents	Meaning
Date & Time	Date format setting	Three formats: (a) year/month/day,(b) month/date/year, (c) date/month/year
	Time setting	Setting time
	Current language	Language in use
Language	Language selection	Simplified Chinese and English selectable (The setting taking action immediately after touching the language icon)
	Device Address	Setting the communication address
	RS232 Protocol Selection	SNT Protocol, Modbus Protocol, YD/T Protocol and Dwin (For factory use)
COMM.	Baud rate	Setting the baud rate of SNT, Modbus and YD/T
	Modbus Mode	Setting mode for Modbus: ASCII and RTU selectable
	Modbus parity	Setting the parity for Modbus
	Output voltage Adjustment	Setting the Output Voltage
	Bypass Voltage Up Limited	Up limited working Voltage for Bypass, settable:+10%, +15%, +20%, +25%
USER	Bypass Voltage Down Limited	Down limited working Voltage for Bypass, settable:-10%, -15%, -20%, -30%, -40%
	Bypass Frequency Limited	Permitted working Frequency for Bypass Settable: +-1Hz, +-3Hz, +-5Hz
	Dust Filter Maintenance Period	Setting Dust Filter Maintenance Period
	Battery Number	Setting the number of the battery (12V)

Submenu Name	Contents	Meaning
BATTERY	Battery Capacity	Setting of the AH of the battery
Float Charge Voltage/Cell		Setting the floating Voltage for battery cell (2V)
	Boost Charge Voltage/Cell	Setting the boost Voltage for battery cell (2V)
	EOD(End of discharge) Voltage/Cell,@0.6C Current	EOD voltage for cell battery,@0.6C current
	EOD(End of charge) Voltage/Cell,@0.15C Current	EOD voltage for cell battery,@0.15C current
	Charge Current Percent	Charge current (percentage of the rated
	Limit	current)
Battery Temperature		Coefficient for battery temperature
	Compensate	compensation
	Boost Charge Time Limit	Setting boost charging time
	Auto Boost Period	Setting the auto boost period
	Auto Maintenance Discharge Period	Setting the period for auto maintenance discharge
SERVICE	System Mode	Setting the system mode: Single , parallel, Single ECO, parallel ECO, LBS, parallel LBS
RATE	Configure the rated Parameter	For the factory use
CONFIGURE	Configure the system	For the factory use

Note

- Users have various permissions to the configuration of the Setting: (a) for the Date &Time, LANGUAGE and COMM, user can set on their own without password. (b)For the USER, a one-level password is needed and the setting must be done by commissioning engineer (c) For the Battery and SERVICE, a Two-level password is needed and it is set by the after-service personal. (d)For the RATE and CONFIGURE, a Three-level password is needed and it is set only by the factory.
- The "C" stands for Ampere number. For instance, if the battery is 100AH, then C=100A.



Warning

Ensure the number of the battery, set via the menu or the monitoring software, is completely equal to the real installed number. Otherwise it will cause serious damage to the batteries or the equipment.

4.2.4 Log

Touch the icon Log, (At the bottom of the screen), and the system enters the interface of the Log, as it is shown in Figure 4-9 Log menu. The log is listed in reverse chronological order (i.e. the first on the screen with #1 is the most new), which displays the events, warnings and faults information and the data and time they occur and disappear.



Figure 4-9 Log menu

The follow Table 4-7 gives the complete list of all the UPS events displayed by history record window and current record window.

Table 4-7 UPS Event List

NO.	UPS events	Description
1	Fault Clear	Manually clear fault
2	Log Clear	Manually clear History log
3	Load On UPS	Inverter feeds load
4	Load On Bypass	Bypass feeds load
5	No Load	No load
6	Battery Boost	Charger is working in boost charging mode
7	Battery Float	Charger is working in float charging mode
8	Battery Discharge	Battery is discharging
9	Battery Connected	Battery is connected already
10	Battery Not Connected	Battery is not yet connected.
11	Maintenance CB Closed	Manual maintenance breaker is closed
12	Maintenance CB Open	Manual maintenance breaker is opened
13	EPO	Emergency Power Off
14	Module On Less	Available power module capacity is less than the load capacity. Please reduce the load capacity or add extra power module to make sure that the UPS capacity is big enough.
15	Generator Input	Generator is connected and a signal is sent to the UPS.
16	Utility Abnormal	Utility (Grid) is abnormal. Mains voltage or frequency exceeds the upper or lower limit and results in rectifier shutdown. Check the input phase voltage of rectifier.
17	Bypass Sequence Error	Bypass voltage Sequence is reverse. Check if input power cables are connected correctly.
18	Bypass Volt Abnormal	This alarm is triggered by an inverter software routine when the amplitude or frequency of bypass voltage exceeds the limit. The alarm will automatically

ı	I	
		reset if the bypass voltage becomes normal.
		First check if relevant alarm exists, such as "bypass circuit breaker open", "Byp
		Sequence Err" and "Ip Neutral Lost". If there is any relevant alarm, first clear this alarm.
		1. Then check and confirm if the bypass voltage and frequency displayed on the
		LCD are within the setting range. Note that the rated voltage and frequency are respectively specified by "Output Voltage" and "Output Frequency".
		2. If the displayed voltage is abnormal, measure the actual bypass voltage and
		frequency. If the measurement is abnormal, check the external bypass power
		supply. If the alarm occurs frequently, use the configuration software to increase
		the bypass high limit set point according to the user's suggestions
19	Bypass Module Fail	Bypass Module Fails. This fault is locked until power off. Or bypass fans fail.
20	Bypass Module Over	Bypass current is over the limitation. If bypass current is under 135% of the
	Load	rated current. The UPS alarms but has no action.
21	Bypass Over Load Tout	The bypass overload status continues and the overload times out.
		This alarm is triggered by an inverter software routine when the frequency of
		bypass voltage exceeds the limit. The alarm will automatically reset if the bypass
		voltage becomes normal.
		First check if relevant alarm exists, such as "bypass circuit breaker open", "Byp
		Sequence Err" and "Ip Neutral Lost". If there is any relevant alarm, first clear this alarm.
22	Byp Freq Over Track	1. Then check and confirm if the bypass frequency displayed on the LCD are
	Jr - 4 - · · ·	within the setting range. Note that the rated frequency are respectively specified
		by "Output Frequency".
		2. If the displayed voltage is abnormal, measure the actual bypass frequency. If
		the measurement is abnormal, check the external bypass power supply. If the
		alarm occurs frequently, use the configuration software to increase the bypass
		high limit set point according to the user's suggestions
		The load is on bypass because the output overload transfer and re-transfer is
23	Exceed Tx Times Lmt	fixed to the set times during the current hour. The system can recover
		automatically and will transfer back to the inverter with 1 hour
		Output shorted Circuit.
24	0 4 40 40 40	Fist check and confirm if loads have something wrong.
24	Output Short Circuit	Then check and confirm if there is something wrong with terminals, sockets or
		some other power distribution unit. If the fault is solved press "Fault Clear" to restart LIPS
		If the fault is solved, press "Fault Clear" to restart UPS. Inverter turned off due to low battery voltage. Check the mains power failure
25	Battery EOD	status and recover the mains power in time
26	Battery Test	System transfer to battery mode for 20 seconds to check if batteries are normal
27	Battery Test OK	Battery Test OK
20	Battery Maintenance	System transfer to battery mode until to be 1.1*EOD voltage to maintenance
28		battery string
20	Battery Maintenance	Battery maintenance succeed
29	OK	
30	Module inserted	Power Module is inserted in system.
31	Module Exit	Power Module is pulled out from system.
32	Rectifier Fail	The N# Power Module Rectifier Fail, The rectifier is fault and results in rectifier
	Income E. T.	shutdown and battery discharging.
33	Inverter Fail	The N# Power Module Inverter Fail. The inverter output voltage is abnormal and
2.4	Partifier Over Town	the load transfers to bypass. The N# Power Module Pactifier Over Temperature. The temperature of the
34	Rectifier Over Temp.	The N# Power Module Rectifier Over Temperature. The temperature of the

ĺ	İ	Landing ICDT in the bight of Landing Community This day is trivial.
		rectifier IGBTs is too high to keep rectifier running. This alarm is triggered by
		the signal from the temperature monitoring device mounted in the rectifier
		IGBTs. The UPS recovers automatically after the over temperature signal
		disappears.
		If over temperature exists, check:
		1. Whether the ambient temperature is too high.
		2. Whether the ventilation channel is blocked.
		3. Whether fan fault happens.
		4. Whether the input voltage is too low.
35	Fan Fail	At least one fan fails in the N# power module.
	Output Over load	The N# Power Module Output Over Load. This alarm appears when the load
		rises above 100% of nominal rating. The alarm automatically resets once the
		overload condition is removed.
		1. Check which phase has overload through the load (%) displayed in LCD so as
36		to confirm if this alarm is true.
		2. If this alarm is true, measure the actual output current to confirm if the
		displayed value is correct.
		Disconnect non-critical load. In parallel system, this alarm will be triggered if
		the load is severely imbalanced.
	Inverter Overload	N# Power Module Inverter Over Load Timeout. The UPS overload status
	Tout	continues and the overload times out.
		Note:
		The highest loaded phase will indicate overload timing-out first.
		When the timer is active, then the alarm "module over load" should also be
37		active as the load is above nominal.
		When the time has expired, the inverter Switch is opened and the load
		transferred to bypass.
		If the load decreases to lower than 95%, after 2 minutes, the system will transfer
		back to inverter mode. Check the load (%) displayed in LCD so as to confirm if
		this alarm is true. If LCD displays that overload happens, then check the actual
	In an art on O and Transia	load and confirm if the UPS has over load before alarm happens.
	Inverter Over Temp.	The N# Power Module Inverter Over Temperature. The temperature of the inverter heat sink is too high to keep inverter running.
		This alarm is triggered by the signal from the temperature monitoring device mounted in the inverter IGBTs. The UPS recovers automatically after the over
		temperature signal disappears.
38		If over temperature exists, check:
		Whether the ambient temperature is too high.
		Whether the ventilation channel is blocked.
		Whether fan fault happens.
		Whether inverter overload time is out.
		Inhibit system transfer from bypass to UPS (inverter). Check:
		Whether the power module's capacity is big enough for load.
39	On UPS Inhibited	Whether the rectifier is ready.
		Whether the bypass voltage is normal.
40	Manual Transfer Byp	Transfer to bypass manually
		Escape from "transfer to bypass manually" command. If UPS has been
41	Esc Manual Bypass	transferred to bypass manually, this command enable UPS to transfer to inverter.
		Battery Voltage is Low. Before the end of discharging, battery voltage is low
42	Battery Volt Low	warning should occur. After this pre-warning, battery should have the capacity
	J	for 3 minutes discharging with full load.
43	Battery Reverse	Battery cables are connected not correctly.
44	Inverter Protect	The N# Power Module Inverter Protect. Check:
44	mverter Frotect	THE 13# 1 OWEL INTOLUTE HIVELUL FIGURES.

ĺ		Whether inverter voltage is abnormal
		Whether inverter voltage is much different from other modules, if yes, please
		adjust inverter voltage of the power module separately.
		The mains neutral wire is lost or not detected. For 3 phases UPS, it's
45	Input Neutral Lost	recommended that user use a 3-poles breaker or switch between input power and
	•	UPS.
46	Bypass Fan Fail	At least one of bypass module Fans Fails
47	Manual Shutdown	The N# Power Module is manually shutdown. The power module shuts down rectifier and inverter, and there's on inverter output.
48	Manual Boost Charge	Manually force the Charger work in boost charge mode.
49	Manual Float Charge	Manually force the charger work in float charge mode.
50	UPS Locked	Forbidden to shutdown UPS power module manually.
	OT S ZOUNGE	Parallel cables error. Check:
		If one or more parallel cables are disconnected or not connected correctly
51	Parallel Cable Error	If parallel cable round is disconnected
		If parallel cable is OK
53	Lost N+X Redundant	Lost N+X Redundant. There is no X redundant powers module in system.
54	EOD Sys Inhibited	System is inhibited to supply after the battery is EOD (end of discharging)
34	EOD Sys Illillotted	Battery Test Fail. Check if UPS is normal and battery voltage is over 90% of
55	Battery Test Fail	
		float voltage.
	Dottom Maintenance	Check
56	Battery Maintenance	If UPS is normal and not any alarms
	Fail	If the battery voltage is over 90% of float voltage If load is over 25%
		Ambient temperature is over the limit of UPS. Air conditioners are required to
57	Ambient Over Temp	regulate ambient temperature.
		Rectifier CAN bus communication is abnormal. Please check if communication
58	REC CAN Fail	cables are not connected correctly.
		IO signal communication of inverter CAN bus is abnormal. Please check if
59	INV IO CAN Fail	communication cables are not connected correctly.
		DATA communication of inverter CAN bus is abnormal. Please check if
60	INV DATA CAN Fail	communication cables are not connected correctly.
		The difference of two or more power modules' output current in system is over
61	Power Share Fail	limitation. Please adjust output voltage of power modules and restart UPS.
		Synchronization signal between modules is abnormal. Please check if
62	Sync Pulse Fail	communication cables are not connected correctly.
		Input voltage of N# power module is abnormal.
		Please check if the input cables are connected correctly.
63	Input Volt Detect Fail	Please check if input fuses are broken.
		Please check if utility is normal.
		Battery voltage is abnormal.
64	Battery Volt Detect	Please check if batteries are normal.
	Fail	Please check if battery fuses are broken on input power board.
65	Output Volt Fail	Output voltage is abnormal.
		Bypass voltage is abnormal.
66	Bypass Volt Detect	Please check if bypass breaker is closed and is good.
	Fail	Please check if bypass cables are connected correctly.
67	INV Bridge Fail	Inverter IGBTs are broken and opened.
		Outlet temperature of power module is over the limitation.
		Please check if fans are abnormal.
68	Outlet Temp Error	Please check if PFC or inverter inductors are abnormal.
		Please check if air passage is blocked.

		Please check if ambient temperature is too high.
		The difference of input current between every two phases is over 40% of rated
		current.
69	Input Curr Unbalance	Please check if rectifier's fuses, diode, IGBT or PFC diodes are broken.
		Please check if input voltage is abnormal.
		Voltage of DC bus capacitors is over limitation. UPS shutdown rectifier and
70	DC Bus Over Volt	inverter.
		While soft start procedures are finished, DC bus voltage is lower than the
		limitation of calculation according utility voltage. Please check
		Whether rectifier diodes are broken
71	REC Soft Start Fail	2. Whether PFC IGBTs are broken
		3. Whether PFC diodes are broken
		4. Whether drivers of SCR or IGBT are abnormal
		5. Whether soft start resistors or relay are abnormal
72	Relay Connect Fail	Inverter relays are opened and cannot work or fuses are broken.
73	Relay Short Circuit	Inverter relays are shorted and cannot be released.
74	PWM Sync Fail	PWM synchronizing signal is abnormal
ļ , .	1 5yno i an	UPS works in intelligent sleep mode. In this mode, the power modules will be
		standby in turn. It will be more reliability and higher efficiency. It must be
		confirmed that remained power modules' capacity is big enough to feed load. It
75	Intelligent Sleep	must be conformed that working modules' capacity is big enough if user add
		more load to UPS. It's recommended that sleeping power modules are waken up
		if the capacity of new added loads is not sure.
	Manual Transfer to	Manually transfer UPS to inverter. It's used to transfer UPS to inverter when
76	INV	bypass is over track. The interrupt time could be over 20ms.
		Input over current timeout and UPS transfer to battery mode.
77	Input Over Curr Tout	Please check if input voltage is too low and output load is big. Please regulate
		input voltage to be higher if it's possible or disconnect some loads.
78	No Inlet Temp. Sensor	Inlet temperature sensor is not connected correctly.
5 0	No Outlet Temp.	
79	Sensor	Outlet temperature sensor is not connected correctly.
80	Inlat Orian Tama	Inlet air is over temperature. Make sure that the operation temperature of UPS is
80	Inlet Over Temp.	between 0-40°C.
81	Capacitor Time Reset	Reset timing of DC bus capacitors.
82	Fan Time Reset	Reset timing of fans.
83	Battery History Reset	Reset battery history data.
84	Byp Fan Time Reset	Reset timing of bypass fans.
85	Battery Over Temp.	Battery is over temperature. It's optional.
		Working life of bypass fans is expired, and it's recommended that the fans are
86	Bypass Fan Expired	replaced with new fans. It must be activated via software.
	 	Working life of capacitors is expired, and it's recommended that the capacitors
87	Capacitor Expired	are replaced with new capacitors. It must be activated via software.
	<u> </u>	Working life of power modules' fans is expired, and it's recommended that the
88	Fan Expired	fans are replaced with new fans. It must be activated via software.
	DILL YOUR T	Inverter IGBTs are shutdown.
89	INV IGBT Driver	Please check if power modules are inserted in cabinet correctly.
	Block	Please check if fuses between rectifier and inverter are broken.
00	D	Working life of batteries is expired, and it's recommended that the batteries are
90	Battery Expired	replaced with new batteries. It must be activated via software.
91	Bypass CAN Fail	The CAN bus between bypass module and cabinet is abnormal.
92	Dust Filter Expired	Dust filter need to be clear or replaced with a new one
/-	2 dot 1 ntor Expired	2 850 11101 11000 to 00 oroni of replaced with a fiew one

102	Wave Trigger	Waveform has been saved while UPS fail
		Bypass and cabinet communicate with each other via CAN bus. Check
103	Bypass CAN Fail	If connector or signal cable is abnormal.
		If monitoring board is abnormal.
105	Firmware Error	Manufacturer used only.
106	System Setting Error	Manufacturer used only.
		Bypass module is over temperature. Please check
		If bypass load is overload
107	Bypass Over Temp.	If ambient temperature is over 40°C
		If bypass SCRs are assembled correctly
		If bypass fans are normal
108	Module ID Duplicate	At least two modules are set as same ID on the power connector board, please set
100	Wiodule 1D Duplicate	the ID as correct sequence



Different colors of the words represent different level of events:

- (a)Green, an event occurs;
- (b)Grey, the event occurs then clears;
- (c)Yellow, warning occurs;
- (d) Red, faults happen.

4.2.5 Operate

Touch the icon (At the bottom of the screen), and the system enters the page of the "Operate", as it is shown in Figure.




Figure 4-10 Operate menu

The "Operate" menu includes FUNCTIONBUTTON and TESTCOMMAND. The contents are described in details below.

FUNTION BUTTON

Clear/Restore Buzzing

Mute or Restore buzzing of the system by touching the icon or

• Fault Clear

Clear the faults by touching the icon

• Transfer to and ESC Bypass

Transfer to bypass mode or cancel this command by touching the icon Transfer to bypass or

Transfer to Inverter

Transfer the bypass mode to Inverter Mode by touching the icon Transfer to Inverter

• Enable Module "OFF" Button

Enable the switch for powering off the Power Module by touching the icon Enable Module 'OFF' Button

• Reset Battery History Data

Reset the battery history data by touching the icon Reset Battery History Data, the history data includes the times of discharge, days for running and hours of discharging.

• Reset Dust filter Using Time

Reset the time of dust filter using by touching the icon reset Dust Finer Using Time, it includes the days of using and maintenance period.

TEST COMMAND

Battery Test

By touching the icon the system transfer to the Battery mode to test the condition of the battery. Ensure the bypass is working normally and the capacity of the battery is no less than 25%.

Battery Maintenance

By touching the icon buttery, which requires the normality of the bypass and minimum capacity of 25% for the battery.

Battery Boost

By touching the icon Battery Maintenance, the system starts boost charging.

Battery Float

By touching the icon Battery Float, the system starts float charging.

Stop Test

By touching the icon stop Test, the system stops battery test or battery maintenance.

4.2.6 Scope

(At the bottom right of the screen), and the system enters the page of the Scope, as it is shown in Figure.

Figure 4-11 Scope Menu

Users can view the waves for output voltage, output current and bypass voltage by touching the corresponding icon in the left side of the interface. The waves can be zoomed in and zoom out.



Touch the icon to display the 3 phase output voltage.



Touch the icon to display the 3 phase output current.



• Touch the icon to display the 3 phase bypass voltage.



Touch the icon to zoom in the wave.



5 Operations

5.1 UPS Start-up

5.1.1 Start in Normal Mode

The UPS must be started up by commissioning engineer after the completeness of installation. The steps below must be followed:

- 1) Ensure all the circuit breakers are open.
- 2) One by one to turn on the output breaker (Q4), input breaker (Q1), bypass input breaker (Q2), and then the system starts initializing (4-slot cabinet and 6-slot cabinet only have a manual bypass breaker, so need to used external circuit breakers).
- 3) The LCD in front of the cabinet is lit up. The system enters the home page, as shown in Figure 3-2.
- 4) Notice the energy bar in the home page, and pay attention to the LED indicators. The rectifier flashes indicating the rectifier is starting up. The LED indicators are listed below in Table 5-1.

Table 5-1 Rectifier starting up

Indicator	Status	Indicator	Status
Rectifier	green flashing	Inverter	off
Battery	red	Load	off
Bypass	off	Status	red

After 30S, the rectifier indicator goes steady green, presenting the finishing of rectification and bypass static switch closes then the inverter is starting up. The LED indicators are listed below in Table 5-2.

Table 5-2 Inverter starting up

Indicator	Status	Indicator	Status
Rectifier	green	Inverter	green flashing
Battery	red	Load	green
Bypass	green	Status	red

 The UPS transfers from the bypass to inverter after the inverter goes normal. The LED indicators are listed below in Table 5-3.

Table 5-3 Supplying the load

Indicator	tor Status Indicator		Status
Rectifier	green	Inverter	green
Battery	red	Load	green
Bypass	off	Status	red

 The UPS is in Normal Mode. Close the battery circuit breakers and the UPS starts charging the battery. The LED indicators are listed below in Table 5-4.

Table 5-4 Normal mode

Indicator	Status	Indicator	Status
Rectifier	green	Inverter	green
Battery	green	Load	green
Bypass	off	Status	green



- When the system starts, the stored setting will be loaded.
- Users can browse all events during the process of the starting up by checking the menu Log.
- Users can check the information of the power module by the keys in the front of it.

5.1.2. Start from Battery

The start from battery is referring to battery cold start. The steps for the start-up are as follows:

- 1. Confirm the battery is correctly connected;
- 2. Turn on the external battery circuit breakers.
- Press the red button for the battery cold start. The system is then powered by the battery. See Figure 5-1







Figure 5-1 the position of the battery cold start button on cabinet

4. Pressed into the cold starting button hole of all the power modules in turns and the power module indicator light are lighted. See Figure 5-2.



cold start button on module

Figure 5-2 the position of the battery cold start button on module

- 5. After that, the system is starting up and the system transfers to battery mode in 60S
- 6. Turn on the external output power supply isolation to supply the load, and the system is working on battery model.



If the LCD monitor is switched off during the cold start, press the cold start button again.

5.2. Procedure for Switching between Operation Modes

5.2.1. Switching the UPS into Battery Mode from Normal Mode

The UPS transfers to Battery model immediately after the utility (mains voltage) is failed or drops down below the predefined limit.

5.2.2. Switching the UPS from Normal Mode into Bypass Mode

Enter the menu Operate, touch the icon "transfer to bypass" and the system transfers to bypass mode.



Warning

Ensure the bypass is working normally before transferring to bypass mode. Or it may cause failure.

5.2.3. Switching the UPS into Normal Mode from Bypass Mode

Enter the menu Operate, touch the icon transfer to inverter and the system transfers to bypass mode.

5.2.4. Switching the UPS from Normal Mode into Maintenance BypassMode

These following procedures can transfer the load from the UPS inverter output to the maintenance bypass supply, which is used for maintaining.

- 1) Transfer the UPS into Bypass mode following section 5.2.2.
- 2) The inverter indicator LED goes out, status indicator LED goes out, the buzzer alarm, the inverter shutdown. The bypass supplies power to loads.
- 3) Turn off the external battery breaker and turn on the maintenance bypass breaker. And the load is powered through maintenance bypass and static bypass.
- 4) Then pull out bypass module. The maintenance bypass supplies power to loads.



6-slot cabinet does not have a manual bypass breaker. It needs optional PDU.

In manual bypass mode (The manual bypass supplies power to loads), dangerous voltages are present on terminal and internal Copper bar.



∆ Warning

Before making this operation, read messages on LCD display to be sure that bypass supply is regular and the inverter is synchronous with it, so as not to risk a short interruption in powering the load.



Danger

If you need to maintain the power module, wait for 10 minutes to let the DC bus capacitor fully discharge before removing the cover.

5.2.5. Switching the UPS into Normal Mode from Maintenance Bypass Mode

These following procedures can transfer the load from the Maintenance Bypass to inverter output:

- 1. Power ON, after 30S, the static bypass turns on, the bypass indicator LED goes green, and the load is powered through maintenance bypass and static bypass;
- 2. Turn off the maintenance bypass breaker and the load is powered through static bypass;
- 3. After 30S, the rectifier starts, the rectifier indicator LED goes green, and then inverter start. After 60S, the system transfers to Normal mode.



6-slot cabinet does not have a manual bypass breaker. It needs optional PDU

5.3 Battery Manual

If the battery is not in use for a long time, it is necessary to test the condition of the battery. Two methods are provided:

Manual Discharging test. Enter the menu Operate, as is shown in Figure and touch the icon "Battery maintenance" but whether will stop discharging when the battery will have 20% of capacity or in low voltage. Users can stop the discharging by touching the "Stop Test" icon.




Figure 5-3 Battery maintenance

- Auto discharging. The system cans maintenance the battery automatically when the setting is done. The setting procedures are as follows.
 - (a) Enable battery auto discharge. Enter the "CONFIGURE" page of the menu Setting, tick the "Battery Auto Discharge" and confirm (This needs to be done by factory).
 - (b) Setting period for battery auto discharge. Enter the "BATTERY "page of the Setting (See Figure), Set the period time in the item "Auto Maintenance Discharge Period" and confirm.




Figure 5-4 Setting period for battery auto discharge



Warning

The load for the auto maintenance discharge should be 20%-100%, if not, the system will not start the process automatically.

5.4 EPO

The EPO button located in the operator control and display panel (with cover to avoid disoperation, see Figure) is designed to switch off the UPS in emergency conditions (e.g., fire, flood, etc.). To achieve this, just press the EPO button, and the system will turn off the rectifier, inverter and stop powering the load immediately (including the inverter and bypass), and the battery stops charging or discharging.

If the input utility is present, the UPS control circuit will remain active; however, the output will be turned off. To completely isolate the UPS, users need to turn off the external mains input supply to the UPS. Users can restart the UPS by powering the UPS again.



Warning

When the EPO is triggered, the load is not powered by the UPS. Be careful to use the EPO function.




Figure 5-5 EPO Button

5.5 Installation of Parallel Operation System

The UPS system can have three cabinets in parallel.

Two UPS cabinets are connected as is shown in Figure .






Figure 5-6 Parallel diagram

The parallel interfaces are located in the back panel of the cabinet, open the panel can see. The parallel terminal is shown in Figure



(a) The parallel interfaces of 6-slot cabinet



(b) The parallel interfaces of 8-slot cabinet

Figure 5-6 Location of the Parallel interface

The control cables for the parallel operation must be connected with all single devices to form a closed loop, as is shown in Figure




Figure 5-7 Parallel connection

For more details of parallel operation, please refer to the "Instruction for Parallel Operation"

6. Maintenance

6.1. Contents of this chapter

This chapter introduces UPS maintenance, including the maintenance instructions of power module, monitor unit and bypass unit and the replacement method of dust filter

6.2. System maintenance instruction

6.2.1. Matters needing attention

Only maintaining engineers can maintain the power module, monitor unit and bypass unit.

- The power module should be disassembled from top to bottom, so as to prevent any inclination from high gravity center of the cabinet.
- To ensure the safety before maintaining power module and monitor unit, use a multimeter to measure the voltage between operating parts and the earth to ensure the voltage is lower than hazardous voltage, i.e. DC voltage is lower than 36Vdc, and AC maximum voltage is lower than 30Vac.
- 3) Monitor unit and bypass unit is not recommended to hot swap; only when UPS is in Maintenance Bypass Mode or UPS is completely powered off, the monitor unit and bypass unit can be disassembled.
- 4) Wait 10 minutes before opening the cover of the power module after pulling out from the Cabinet.

6.2.2. Instruction for Maintaining Power module

Confirm the UPS is operating in Normal Mode and the bypass is working normally before pulling out the power module needed to be repaired.

- 1) Ensure the remaining power module will not be overloaded.
- 2) Power off the power module:
 - Enable. LCD panel->Menu Operate __->Enable Module "OFF" icon Enable Module
 - b) Press the "OFF" button on the power module panel for 3 seconds, the power module quits from the system.
- Remove the mounting screw on the two front sides of the power module and pull out the power module by two
 persons.
- 4) Wait 10minutes before opening the cover for repairing.
- 5) After the repairing is done, push the power module into the cabinet and the power module will automatically join the system.

6.2.3. Maintaining monitor unit and bypass unit for 6-slot cabinet

Confirm the UPS is operating in Normal mode and the bypass is working normally:

- 1) Transfer the system to bypass mode through the LCD control panel.
- 2) Turn on the maintenance bypass breaker. The load is powered through maintenance bypass and static bypass.
- 3) One by one to turn off the battery breaker, input breaker, bypass input breaker and output breaker. The load is powered through maintenance bypass.
- 4) Take out power modules,
- 5) Take out power module
- 6) Use multimeter to measure the voltage value of each terminal of UPS to PE, and ensure that UPS is completely power off so as to avoid electric shock
- 7) After the completion of maintenance, insert power module and tighten the screws on both sides of the power module
- 8) One by one to turn on the output breaker, bypass input breaker, input breaker and battery breaker.
- After 2 minutes, the bypass indicator LED goes green, and the load is powered through maintenance bypass and static bypass.
- 10) Turn off the maintenance bypass breaker.
- 11) After 30S, the rectifier starts, the rectifier indicator LED goes green, and then inverter starts. After 60S, the system transfers to Normal mode.
- 12) Close Battery Breaker.

6.2.4. Maintaining monitor unit and bypass unit for 8-slot cabinet

UPS is in normal mode, bypassing normal operation:

- 1) Transfer the system to bypass mode through the LCD control panel.
- 2) Close the manual bypass breaker.
- 3) Close the maintenance bypass breaker.
- 4) One by one to turn off the battery breaker, input breaker, bypass input breaker and output breaker. The load is powered through maintenance bypass.
- 5) Use multimeter to measure the voltage value of each terminal of UPS to PE, and ensure that UPS is completely power off so as to avoid electric shock
- 6) Bypass module and cabinet maintenance
- 7) One by one to turn on the output breaker, bypass input breaker, input breaker and battery breaker.
- 8) After 2 minutes, the bypass indicator LED goes green, and the load is powered through maintenance bypass and static bypass.
- 9) Disconnect the maintenance bypass breaker.
- 10) Disconnect the manual bypass breaker. After 30S, the rectifier starts, the rectifier indicator LED goes green, and then inverter starts. After 60S, the system transfers to Normal mode.
- 11) Close Battery Breaker.



Danger

UPS without external power distribution switch could be electrified on manual bypass mod, please don't touch it so as to avoid electric shock.

6.2.5. Battery maintenance

Generally, maintenance free batteries do not require manual maintenance when using. Operate according to certain requirements. The life of the battery can be prolonged. The factors that affect battery life are as follows: installation, temperature, charging and discharging current, charging voltage, discharge depth and long-term charging.

- 1. Installation. Batteries should be installed as clean as possible, in a cool, airy, dry place, avoiding exposure to direct sunlight or other radiant heat sources. When installing the battery, pay attention to the accuracy and quantity of the battery. The batteries with different specifications and batch numbers should not be mixed.
- 2. Temperature. Keep the temperature of the battery at about 25° C.
- 3. Charge discharge current. The optimum charging current of lead-acid battery is about 0.1C, and the charging current must not be greater than 0.3C. Charging current is too large or too small, will affect the battery life. Discharge current is generally required at 0.05~3C.
- 4. Charging voltage. Because the UPS battery belongs to the standby mode, the battery will be discharged only when the power supply is abnormal or the battery will be charged. To prolong the life of battery charger, UPS generally uses the constant voltage/current limiting control, after the battery is turned into floating state, each section of the floating voltage set to about 13.7V. If the charge voltage is too high, the battery will be overcharged; otherwise the battery will not be charged enough.
- Discharge depth. The deeper the discharge depth is, the less cycle times to be, so the depth discharge should be avoided. UPS in the case of light load discharge or no-load discharge will cause deep discharge of the battery.
- 6. Regular maintenance. The battery should be checked regularly, such as observing its appearance and measuring the voltage of the battery. If the battery is not discharged for a long time, the activity will become worse, so the UPS also needs periodic discharge test to keep the battery active.

7. Check the battery regularly for leakage, deformation and so on.

7. Product Specification

7.1. Contents of this chapter

This chapter provides the specifications of the product, including environmental characteristics mechanical characteristics and electrical characteristics

7.2. Applicable Standards

The UPS has been designed to conform to the following European and international standards shown in Table

Table 6-1 Compliance with European and International Standards

Item	Normative reference
General safety requirements for UPS used in operator access areas	EN50091-1-1/IEC62040-1-1/AS 62040-1-1
Electromagnetic compatibility (EMC) requirements for UPS	EN50091-2/IEC62040-2/AS 62040-2 (C3)
Method of specifying the performance and test requirements of UPS	EN50091-3/IEC62040-3/AS 62040-3 (VFI SS 111)

Note

The above mentioned product standards incorporate relevant compliance clauses with generic IEC and EN standards for safety (IEC/EN/AS60950), electromagnetic emission and immunity (IEC/EN/AS61000 series) and construction (IEC/EN/AS60146 series and 60950).

7.3. Environmental Characteristics

Table 6-2 Environmental Characteristics

Item	Unit	Requirements
Acoustic noise level at 1 meter	dB	65dB @ 100% load, 62dB @ 45% load
Altitude of Operation	m	≤1000,load derated 1% per 100m from 1000m and 2000m
Relative Humidity	%RH	0-95, non-condensing
Operating Temperature	$^{\circ}$ C	0-40,Battery life is halved for every 10°C increase above 20°C
UPS Storage Temperature	$^{\circ}$	-40-70
Recommended battery storage temperature	$^{\circ}$	-20~30

7.4. Mechanical Characteristic

The main physical parameters of the cabinet shows in Table

Table 6-3 Mechanical Characteristics for Cabinet

Model	Unit	6-slot Cabinet	8-slot Cabinet
Mechanical Dimension (W*D*H)	mm	482*916*931	482*916*1550
Weight	kg	140	160
color	N/A	Black	Black
Protection Level, (IEC60529)	N/A	IP20	IP20

The main physical parameters of the cabinet shows in Table

Table 6-4 Mechanical Characteristics for power module

Model	Unit	power module
Mechanical Dimension (W*D*H)	mm	436*677*85
Weight	kg	18

7.5. Electrical Characteristics

7.5.1. Electrical Characteristics (Input Rectifier)

The main electrical features of the rectifier are shown in Table

Table 6-5 Rectifier AC input (Mains)

Item	Unit	Parameter
Grid System	\	3 Phases + Neutral + Ground
Rated AC Input Voltage	Vac	380/400/415(three-phase and sharing neutral with the bypass input)
Rated Frequency	Vac	50/60Hz
Input voltage range	Vac	304~478Vac (Line-Line),full load 228V~304Vac (Line-Line),load decrease linearly according to the min phase voltage
Input Frequency range	Hz	40~70
Input Power factor	PF	>0.99
THDI	THDI%	<3% (full Linear Load)

7.5.2. Electrical Characteristics (Intermediate DC Link)

Table 6-6 Battery

Items	Unit	Parameters
Battery bus voltage	Vdc	Rated: ±240V
Quantity of lead-acid	Nominal	40=[1 battery(12V)],240=[1 battery(2V)]
cells	- 1	
Float charge voltage	V/cell (VRLA	2.25V/cell(selectable from 2.2V/cell~2.35V/cell)
Troat charge voltage)	Constant current and constant voltage charge mode

Temperature compensation	mV/℃/cl	3.0(selectable:0~5.0)
Ripple voltage	%	≤1
Ripple current	%	≤5
Equalized	VRLA	2.4V/cell(selectable from : 2.30V/cell~2.45V/cell)
charge voltage	VKLA	Constant current and constant voltage charge mode
		1.65V/cell(selectable from: 1.60V/cell~1.750V/cell)
		@0.6C discharge current
Final	V/cell (VRLA	1.75V/cell (selectable from: 1.65V/cell~1.8V/cell)
discharging voltage)	@0.15C discharge current
		(EOD voltage changes linearly within the set range according to
		discharge current)
Dottow: Charge	V/cell	2.4V/cell(selectable from : 2.3V/cell~2.45V/cell)
Battery Charge	ttery Charge V/cell	Constant current and constant voltage charge mode
Battery Charging Power	kW	10%* UPS capacity (selectable from : 1~20%* UPS capacity)
Max Current	KVV	1070 OTS capacity (selectable from 17-2070 OTS capacity)

Note: the default number of batteries is 40, please see the UPS battery voltage identification on the nameplate before installation, if the battery number is not 40, please change the settings, and then connect the battery, otherwise the risk of damage. Please contact the manufacturer's customer service phone about the operation steps.

7.5.3. Electrical Characteristics (Inverter Output)

Table 6-7 Inverter Output (To critical load)

Item	Unit	Value
Rated capacity	(kVA)	25-200
Rated AC voltage	Vac	380/400/415 (Line-Line)
Rated Frequency	Hz	50/60
Frequency Regulation	Hz	50/60Hz±0.1%
Voltage precision	%	±1.5(0~100% linear load)
		110%, 60min;
Overload		125%,10min;
Overioad		150%,1min;
		>150%,200ms
Synchronized Range	Hz	Settable, ±0.5Hz ~±5Hz, default ±3Hz
Synchronized Slew Rate	Hz	Settable, 0.5Hz/S ~ 3Hz/S, default 0.5Hz/S
Output Power Factor	PF	1
Transient Response	%	<5% for step load (20% - 80% -20%)
Transient recovery		< 30ms for step load (0% - 100% -0%)
O to t Wilton THD		<1% from 0% to 100% linear load
Output Voltage THDu		<6% full non-linear load according to IEC/EN62040-3

7.5.4. Electrical Characteristics (Bypass Mains Input)

Table 6-8 Bypass Mains Input

Rated capacity	KVA	25-200		
Rated AC voltage	Vac	380/400/415 (three-phase four-wire and sharing neutral with the bypass)		
Rated Current	A	38~303(see Table)		
Overload	%	110%, Long term operation 110%~125%, 5 min 125%~150%, 1min >150%, 1s		
Current rating of neutral cable	A	1.7×In		
Rated frequency	Hz	50/60		
Switch time (between bypass and inverter)	mS	≤2mS		
Bypass voltage range	%	Settable, default -20%~+15% Up limited: +10%, +15%, +20%, +25% Down limited: -10%, -15%, -20%, -30%, -40%	Settable, default -20%~+15% Up limited: +10%, +15%, +20%, +25% Down limited: -10%, -15%, -20%, -30%, -40%	
Bypass frequency range	Hz	Settable, ±1Hz, ±3Hz, ±5Hz Settable, ±1Hz, ±3Hz, ±5Hz		
Synchronized Range	Hz	Settable ±0.5Hz~±5Hz,default ±2Hz	Settable ±0.5Hz~±5Hz,default ±2Hz	

7.6. Efficiency

Table 6-9 Efficiency

Item	Unit		Value		
Overall efficiency					
Normal mode(dual conversion)		%	>96		
ECO mode		%	>98		
Battery discharging efficiency (battery at nominal voltage 480Vdc and full-rated linear load)					
Battery mode		%	>96		

7.7. Display and Interface

The system display and interface are shown in Table


Table 6-10 System display and interface


Display	LED + LCD + Touch screen
Interface	Standard:RS232, RS485, Dry Contact
merace	Option: SNMP,

Appendix I.

6-slot cabinet options PDU introduction

PDU is optional for 6-slot cabinet. The fittings can only be configured by the manufacturer. Size diagram of 6 module cabinet with PDU shows in Figure 0-1 $\,$










Figure 0-1 Size diagram of 6 module cabinet with PDU

PDU Terminal layouts see Figure 0-2



(a) Layout of single input terminals



(b) Layout of Dual input terminals

Figure 0-2 PDU Terminal layout

PDU only support top cable entry, see Figure 0-3




Figure 0-3 PDU Cable entry